

TEMPERATURE SENSOR

STI

cod. 6100-131000



* Civil series > p. 97



It measures the temperature of the room where it is installed. It is composed of an NTC sensor and is installed in a standard blank insert.

It must be installed at 150/170 cm from the ground, in specific box away from heat sources or air draughts.

Weight: 0.03 kg. Depth 35mm.

FANCOIL THERMOSTAT PANEL

PTF

cod. 6100-133000



* Civil series > p. 97



It allows the guest to change temperature, speed, automatic or manual operation and switch off air conditioning. The display shows time, set and measured temperature values, speed, window status, and help call. The light sensor optimises contrast and luminous symbols provide information on operation status. The panel allows the staff to reset bathroom and flood alarms and set the "clean room" and "full mini-bar" conditions. It is housed in 3-module box and connected to the control unit with 6-wire cable terminated with RJ12 PLUG.

Weight: 0.1 kg. Depth 45mm.